

Filter-Klear™ Kwik Start Guide

Step 1. Position Filter-Klear as close as possible to the fountain solutions treatment tank



Step 2. Install Filter Klear hoses into sides of fountain solution tank, allowing space between hoses for circulation



Step 3. Select Quick Connect air line fitting that matches existing compressed air hose and insert into air line. Tighten with wrench



Step 4: Connect compressed air line and turn on air valve



Step 5. Set regulator by pulling up knob and turning until air pressure reads 20 psi. Push knob down to lock in place



Step 6. Open the Air Bleed Valve and vent the air as the filters fill. Once all the air has been removed, close the vent. The system is now ready for normal operation



CAUTION: DO NOT EXCEED 20 PSI ON INITIAL PRESSURE SETTING TO AVOID EMPTYING FOUNTAIN SOLUTION TANK ALWAYS WEAR EYE PROTECTION WHEN STARTING UP THE FILTER KLEAR SYSTEM.